



4-Row Fully-Automatic FiberCell Filler

4-ROW FULLY-AUTOMATIC FIBERCELL FILLER

Key Features:

BCC's FiberCell Filling machines are in the forefront of development. We know there is not a unilateral solution working for all clients around the world. We add our know-how and experience to make sure you get exactly the right set-up to optimize your business.

Our FiberCell filling machines are durable and of the highest quality standards. BCC FiberCell stands for reliability, good functionality, and minimal downtime, which offers our customers high efficiency in their operations.

The cells are filled and cut in the 4-Row Fully-Automatic FiberCell Filler. The cells are then transferred on the four transport lines where they are automatically placed in the tray by the 4-Row Fully-Automatic Placing Unit.



TECHNICAL DATA

Specifications	4-Row Fully-Automatic Filler
Dimensions (LxWxH) mm	8960 x 2140 x 2440
Weight (kg)	Approx. 2000 kg
Capacity	Up to 18 000 cells/hour
FiberCell material size (diameter - length), mm	Row 1: Ø15-40mm Row 2: Ø15-40mm Row 3: Ø15-40mm Row 4: Ø15-40mm
Cell length	20-70 mm
Standard power supply, V/Hz/ Amps	3x400 V AC, N, PE, 12A, 4kW
Compressed air cons., lit/min	1000l at 6,5 bar minimum pipe dimension: 18mm

