



FIBERCELL

2-Row Semi-Automatic XL FiberCell Filler

FIBERCELL XL FILLER

Key Features:

The FiberCell XL Filling Machine is two independent machines in one, and the pipeline works independently from each other. It has a removable vacuum box for easy cleaning and has an ergonomic work height. It is simple to adjust the density and air content of the paper plugs.

Our Semi-automatic FiberCell Fillers are ideal for smaller and medium sized nurseries. The machines are designed for efficient operations with low downtime and minimal peat spill with fine cuttings. The Semi-automatic FiberCell Fillers are compact and simplicity rules when installing, setting up, operating, and maintaining it.

The FiberCell XL machine is more automatized with a remote access system and an automatic peat level sensor. It has a color touch screen panel for easy configuration. The machine is user friendly and has a modern design and solid construction. Our FiberCell machines are designed to perform accurately year after year!



TECHNICAL DATA

Specifications	2-Row Semi-Automatic XL Filler
Dimensions (LxWxH) mm	Approx. 3400 x 1550 x 2450
Weight (kg)	1 100 kg
Capacity	Up to 3000 cells/hour (depending on cell length, cell diameter and substrate)
Cell diameter (mm)	Ø90, 100 and 120
Cell length (mm)	Adjustable
Standard power supply, V/Hz/ Amps	3x400V 50/60 Hz, 16A
Compressed air cons., lit/min	800 liters/minute
Air pressure, Bar	6

