



2-Row Fully Automatic FiberCell Filler

2-ROW FULLY AUTOMATIC FIBERCELL FILLER

Key Features:

The 2-Row fully automatic placing unit can place plugs with cell diameter between 40 - 60 mm. It is easy to adjust the cell length and can have a length up to 100 mm. It can be integrated with a destacking unit for automatically feeding trays to the machine and it can be adapted to many different trays. The machine is easy to handle, easy to clean and can be operated by one person.

The machine can produce up to 4000 cells/hour depending on cell length, cell diameter and substrate. The spike dibbler can be adjusted to the different trays used in the machine and you can choose in which pattern the cells should be placed in the tray.



TECHNICAL DATA

Specifications	2-Row Fully Automatic FiberCell Filler
Dimensions (LxWxH) mm	6750 x 1870 x 2500
Weight (kg)	Approx. 2000 kg
Electrical Power	3x400 V, 50/60 Hz 16 A + 10 A
Compressed Air	700l at 6 bar
Capacity	Up to 4000 cells/hour
FiberCell diameter (mm)	Ø40-60mm
FiberCell length (mm)	50 - 100mm

